



# TECHNICAL DATA SHEET - PRODUCT **HEXISGEL**

HEXISGEL facilitates the application of adhesive-coated films (BODYFENCEB, V202CGI, Cristal, PURE ZONE®, etc.) by reducing the application time compared with other liquids, like soapy water or our EASYPOSE product. Its properties allow to reduce the initial tack in order to easily fit the film position. Its composition enables it to be quickly evacuated to obtain optimum and fast adhesion to the substrate.

## **COMPOSITION:**

- Water
- Isopropanol: < 5 %</li>

#### **LIQUID FEATURES:**

Colourless liquid

### **USER'S INSTRUCTIONS:**

- Shake the bottle before use.
- Thoroughly spray the HEXISGEL on the application surface and each film side.
- Position and adjust the film on the substrate.
- Remove the HEXISGEL and any air bubbles located between the film and the substrate by firmly applying a squeegee from the centre towards the edges.
- Finalize the application by wiping off HEXISGEL residues with a clean and dry cloth.

The safety data sheet is available upon request.

### **STORAGE:**

- Keep the HEXISGEL in its original container securely closed, at ambient temperature and protected from direct sunlight.
- Shelf life: I year if it is stored unopened in its original container.

#### **NOTES:**